










## MC9090 Accessories (continued)










Miscellaneous (continued)	
	<b>Headset</b> 50-11300-050R Wired plug-in headset for superior and convenient use.
	<b>UBC2000 Wall Mount Kit</b> KT-32665-01R Use for mounting UBC2000 onto a wall.
No photo available	<b>Voice Picking Kit</b> KT-104458-01R Includes holster.
No photo available	<b>Voice Picking Kit</b> KT-104458-02R Without holster.









## MC9090 Accessories (continued)

Miscellaneous (continued)	
	<p><b>Stylus Kit</b> 11-43912-03R</p> <p>Replacement gray stylus with tether for MC90XX-G (3-pack).</p>
	<p><b>Stylus Kit</b> 11-43912-50R</p> <p>Replacement gray stylus with tether for MC90XX-G (50-pack).</p>
	<p><b>Tether Kit</b> 11-42722-03R</p> <p>Contains three tethers for connecting a stylus to the MC906X-K/S and MC909X-K/S.</p>
	<p><b>Tether Kit</b> 11-42722-50R</p> <p>Contains 50 tethers for connecting a stylus to the MC906X-K/S and MC909X-K/S.</p>
	<p><b>Stylus Kit</b> KT-85555-03R</p> <p>Replacement yellow stylus for MC90X-K/S (3-pack).</p>
	<p><b>Stylus Kit</b> KT-85555-10R</p> <p>Replacement yellow stylus for MC90X-K/S (10-pack).</p>
	<p><b>Stylus Kit</b> 160-0362R</p> <p>Replacement dark gray stylus (3-pack).</p>
	<p><b>Rugged Hand Strap</b> SG-MC9023204-01R</p> <p>Replacement rugged handstrap for the MC906X-S configuration.</p>
	<p><b>Rugged Hand Strap</b> SG-MC9023204-02R</p> <p>Replacement rugged handstrap for the MC909X-S configuration.</p>
	<p><b>Belt Clip</b> KT-70147-01R</p> <p>For use with the MC90XX-G only. Attaches to a user's belt.</p>











## MC9090 Accessories (continued)

Soft Goods (continued)	
	<p><b>Heated Boot</b> SG-MC9024242-01R</p> <p>Allows MC9090 Condensation Resistant Gun configuration to be used in freezer applications.</p>
Snap-on	
	<p><b>Modem Module</b> MDM9001-C010R</p> <p>Snaps on to the MC90XX and provides modem connectivity.</p>
	<p><b>Magnetic Stripe Reader</b> MSR9001-100R</p> <p>Captures data from magnetic stripe cards.</p>
	<p><b>Modem Dongle</b> MDM9000-100R</p> <p>Provides modem connectivity to the MC9000 through the terminal or the single slot cradle.</p>
Miscellaneous	
	<p><b>MC90XX Wall Mounting Bracket</b> KT-61498-01R</p> <p>Order one for Single Slot cradle and one for the SAC9000. Order two for Four Slot Cradles. Order Cradle Bracket separately to attach to the wall mount bracket.</p>
	<p><b>MC90XX Cradle Bracket</b> KT-61499-01R</p> <p>Order one for Single Slot cradle and one for the SAC9000. Order two for Four Slot Cradles. Attaches to the bottom of the cradle.</p>
	<p><b>Screen Protector</b> KT-93176-03R</p> <p>Adds an additional level of protection for the MC90XX screen to protect against scratches. (3-pack).</p>
	<p><b>Stylus Kit</b> KT-81680-50R</p> <p>Replacement gray stylus with tether for MC9090-G (50-pack).</p>
	<p><b>Stylus Kit</b> KT-81680-03R</p> <p>Replacement gray stylus with tether for MC9090-G (3-pack).</p>

## MC9090 Accessories (continued)

Cables (continued)	
	<p><b>Serial Cable</b> 25-63852-01R</p> <p>Provides serial communication from the Single Slot Serial/USB cradle to a host computer.</p>
Soft Goods	
	<p><b>Protective Boot</b> 11-67218-04R</p> <p>Provides additional protection for MC90XX-G configurations.</p>
	<p><b>Shoulder Strap</b> 58-40000-007R</p> <p>Universal shoulder strap for holster (SG-MC9021210-01R).</p>
	<p><b>Holster</b> SG-MC9021210-01R</p> <p>Soft material holder for MC90XX-G only.</p>
	<p><b>Belt</b> 11-08062-01R</p> <p>For Holster (11-64896-01) for MC90XX-G only.</p>
	<p><b>Quick Release Holster</b> SG-MC9021110-01R</p> <p>Soft material holder with belt clip for MC90XX-K only.</p>
	<p><b>Quick Release Holster</b> SG-MC9021110-02R</p> <p>Soft material holder with belt clip for MC90XX-S only.</p>
	<p><b>Handstrap Kit</b> KT-66447-03R</p> <p>Replacement handstraps for the MC9000-G (3-pack).</p>
	<p><b>Handstrap Kit</b> SG-MC9023241-90R</p> <p>Replacement handstraps for the MC9090-K (5-pack).</p>
	<p><b>Handstrap Kit</b> SG-MC9023241-60R</p> <p>Replacement handstraps for the MC9060-K (5-pack).</p>

## MC9090 Accessories (continued)

Cables (continued)	
	<p><b>RS232 Cable</b> 25-62164-01R</p> <p>Provides serial communication to the host or printer and can be used for AC charging. Requires cable adapter module (ADP9000-100R must be ordered separately).</p>
	<p><b>USB Cable</b> 25-62166-01R</p> <p>Provides USB communication to the host and can be used for AC charging. Requires cable adapter module (ADP9000-100R must be ordered separately).</p>
	<p><b>DEX Cable</b> 25-62167-02R</p> <p>Requires cable adapter module (ADP9000-100R must be ordered separately).</p>
	<p><b>DEX Cable with Floating Jack Screws</b> 25-62167-03R</p> <p>Requires cable adapter module (ADP9000-100R must be ordered separately).</p>
	<p><b>Printer Cable</b> 25-62168-01R</p> <p>Connects the MC9000 to a Paxar printer. Requires Cable Adapter Module (ADP9000-100R).</p>
	<p><b>Printer Cable</b> 25-62169-01R</p> <p>Connects the MC9000 to an O'Neil printer. Requires Cable Adapter Module (ADP9000-100R).</p>
	<p><b>Printer Cable</b> 25-62170-02R</p> <p>Connects the MC9000 to a Zebra QL series printer. Requires Cable Adapter Module (ADP9000-100R).</p>
	<p><b>Modem Cable</b> 25-63856-01R</p> <p>Allows single slot cradle to be used as a modem cradle.</p>
	<p><b>Cable Adapter Module</b> ADP9000-110R</p> <p>Attaches to the bottom of the MC909X. Provides power (5 VDC 350 mA) for use with the LS3408ER scanner.</p>
	<p><b>Cable Adapter Module</b> ADP9000-100R</p> <p>Attaches to the bottom of the MC909X. Provides power for operating and charging the MC909X and provides serial communication.</p>










## MC9090 Accessories (continued)

Charging (continued)	
	<p><b>Four Slot Battery Charger</b> SAC9000-4000R</p> <p>Charges up to four MC9000 batteries. Requires power supply (50-14000-242R), DC line cord (50-16002-011R) and AC line cord. To charge an MC90XX-S battery purchase BAP9000-100R battery adapter.</p>
	<p><b>Spare Battery</b> BTRY-MC90SAB00-01</p> <p>For MC90XX-S only (1550 mAh).</p>
	<p><b>UBC Adapter Power Supply Kit</b> KT-32665-02R</p> <p>Includes power supply (50-14001-013R), DC cable (50-16002-004R) and four rubber feet.</p>
	<p><b>Power Supply</b> KT-14000-148R</p> <p>100 - 240 VAC input, 12 VDC 3.33 A output.</p>
	<p><b>Power Supply</b> 50-14000-242R</p> <p>85 - 264 VAC input, 15 VDC 5 A output.</p>
	<p><b>Power Supply</b> 50-14000-241R</p> <p>90 - 264 VAC input, 12 VDC 9 A output.</p>
	<p><b>DC Line Cord</b> 50-16002-029R</p> <p>Provides power from the power supply to the four slot cradle.</p>
	<p><b>DC Line Cord</b> 25-72614-01R</p> <p>Compatible with power supply 50-14000-242R.</p>
Cables	
	<p><b>USB Sync Cable</b> 25-64396-01R</p> <p>Provides USB communication with a host computer through the MC9000 Single Slot and Four Slot Cradles.</p>

## MC9090 Accessories (continued)

Cradles (continued)	
	<p><b>Vehicle Cradle</b> VCD9000-K000R</p> <p>Provides secure mounting of the MC909X-K in a vehicle. Charges the MC909X-K and a spare battery. Provides a serial port for data communication between an MC909X-K and an external device. Includes power cable.</p>
	<p><b>Vehicle Cradle</b> VCD9000-K010R</p> <p>Provides secure mounting of the MC909X-K in a vehicle. Charges the MC909X-K and a spare battery. Provides a serial port for data communication between an MC909X-K and an external device. Includes power cable. Spare battery charger reverse mounted.</p>
	<p><b>Vehicle Cradle</b> VCD9000-S000R</p> <p>Provides secure mounting of the MC909X-S in a vehicle. Charges the MC909X-S and a spare battery. Provides a serial port for data communication between an MC909X-S and an external device. Includes power cable.</p>
	<p><b>Spare Battery Adapter for MC90XX-S battery (BTRY-MC90SAB00-01)</b> BAP9000-100R</p> <p>The adapter is required to charge an MC90XX-S spare battery in the CRD9000-1001SR cradle or the SAC9000-4000R charger.</p>
Charging	
	<p><b>Universal Battery Charger Adapter</b> 21-32665-48R</p> <p>Charges an MC909X-K or -G battery as a stand-alone charger or with the UBC2000 base.</p>
	<p><b>Universal Battery Charger Adapter</b> 21-32665-38R</p> <p>Charges an MC909X-S battery as a stand-alone charger or with the UBC2000 base.</p>
	<p><b>UBC Four Slot Base</b> UBC2000-I500DR</p> <p>Includes power supply (50-14000-242R) and DC cable (50-16002-011R). Requires AC line cord.</p>
	<p><b>12 Volt Auto Charge Cable (cigarette lighter)</b> VCA9000-12R</p> <p>Requires Cable Adapter Module (ADP9000-100R).</p>
	<p><b>24 Volt Auto Charge Cable (cigarette lighter)</b> VCA9000-24R</p> <p>Requires Cable Adapter Module (ADP9000-100R).</p>

# MC9090 Accessories

Cradles	
	<p><b>Single Slot Serial/USB Cradle</b> CRD9000-1001SR</p> <p>Cradle enables Serial or USB communication between the MC9000 and a host PC. The cradle also charges the MC9000 with a standard battery and a standard spare battery stored in the cradle.</p>
	<p><b>Single Slot Serial/USB Cradle Kit</b> CRD9000-110SR</p> <p>Includes cradle (CRD9000-1001SR), power supply (KT-14000-148R) and AC line cord (23844-00-00R).</p>
	<p><b>Single Slot Serial/USB Cradle Kit</b> CRD9000-111SR</p> <p>Includes cradle (CRD9000-1001SR) and power supply (KT-14000-148R).</p>
	<p><b>Four Slot Charge Only Cradle</b> CHS9000-4001CR</p> <p>Cradle charges up to four MC9000s simultaneously in approximately two hours. Ideal for customers who communicate wirelessly but need a cradle for battery charging.</p>
	<p><b>Four Slot Charge Only Cradle Kit</b> CRD9000-410CR</p> <p>Includes cradle (CHS9000-4001CR), power supply (50-14000-241R), DC line cord (50-16002-029R) and AC line cord (23844-00-00R).</p>
	<p><b>Four Slot Charge Only Cradle Kit</b> CRD9000-411CR</p> <p>Includes cradle (CHS9000-4001CR), power supply (50-14000-241R) and DC line cord (50-16002-029R).</p>
	<p><b>Four Slot Ethernet Cradle</b> CRD9000-4001ER</p> <p>Provides communication via Ethernet between the MC9000 and a host PC. The cradle also charges the mobile computer with a standard battery.</p>
	<p><b>Four Slot Ethernet Cradle Kit</b> CRD9000-410ER</p> <p>Includes cradle (CRD9000-4001ER), power supply (50-14000-241R), DC line cord (50-16002-029R) and AC line cord (23844-00-00R).</p>
	<p><b>Four Slot Ethernet Cradle Kit</b> CRD9000-411ER</p> <p>Includes cradle (CRD9000-4001ER), power supply (50-14000-241R) and DC line cord (50-16002-029R).</p>